

**onbon** 仰邦科技

# USER MANUAL

Ledmedia Y SERIES APP

VERSION: V1.1    DATE: 2020.6.12

## STATEMENT

Any companies or privates cannot copy, transcribe or translate part or whole content of this file without our written permission. And cannot use it on any business or benefit filed with any forms.

The specifications and information which are mentioned on the file is for reference only, if there' s update, we will not inform you. This file is only for guidance, and all information will not be for any promises.

# CATALOG

<b>STATEMENT</b> .....	2
<b>CATALOG</b> .....	3
<b>Brief Introduction</b> .....	5
<b>About Software</b> .....	5
<b>Summarization</b> .....	6
<b>Install and Uninstall</b> .....	6
<b>Install software</b> .....	6
<b>Uninstall software</b> .....	6
<b>Edit and send programs</b> .....	7
<b>Connect with controller</b> .....	7
<b>Add screen</b> .....	8
<b>Add program</b> .....	9
<b>Add area</b> .....	10
<b>Send program</b> .....	13
<b>Manage program</b> .....	14
<b>Function setting</b> .....	14
<b>Set ON/OFF</b> .....	14
<b>Timing on/off</b> .....	14
<b>Correction time</b> .....	14
<b>Brightness</b> .....	14
<b>Volume</b> .....	14

<b>Set screen parameters</b> .....	14
<b>Switch storage</b> .....	14
<b>WIFI configuration</b> .....	15
<b>Firmware update</b> .....	15
<b>Other settings</b> .....	15
<b>Language</b> .....	15
<b>Clean cache</b> .....	15
<b>App Share APP</b> .....	15
<b>Version</b> .....	15

## **Brief Introduction**

Thanks for choosing LED control card. The design of the control card is according to the international and industrial standard, but if the operations are incorrect, it will probably bring you personal injury and financial harm. As to avoid these and win more from your equipment, please obey the specifications of this file.

## **About Software**

Cannot do any modification, decompilation, disassembling, decoding or reverse engineering on our software, it' s illegal.

## Summarization

Software supports text, picture, video, time, dial, colorful words, colorful background, weather, sensor areas, and supports turn on/off, correction time, adjust brightness, set parameters, WIFI configuration, program time, displaying times, alignment, program frame, adjust brightness by time, timing ON/OFF, etc.

## Install and Uninstall

### Install software

Users can download “Ledmedia” in APP Store, download from our website or scan below QR code.



### Uninstall software


Long press “Builder” , until you can cancel.

## Edit and send programs

Below is the example to connect with BX-Y3.

### Connect with controller


Method 1: Search controller WIFI name in your WLAN, input correct passwords. (default passwords is the last 8 digits of barcode)




Method 2: Controller connects with wireless router, mobile phone connect controller by wireless router. Search name in WLAN of your mobile phone.



## Add screen


In "screen list" page of Ledmedia, click "search" , click  in "search result" , as to search online controller automatically. Select the controller you need to add in , click "OK" as to add screen. And modify equipment name, screen width, height pixels in "add screen" page.



## Main page of software

Software page includes screen list, equipment function setting, Common use setting area.

Equipment function setting includes ON/OFF setting, auto ON/OFF, correction time, brightness, volume, set screen parameters, switch storage, WiFi configuration, firmware update, etc.



Click  icon behind equipment name, then modify equipment name.






## Add program

Select one screen in ScreenList, click "add screen", enter to the page of editing program.












## Add area

Click add button  , select program area you need to add in.




### 1. Buttons in editing page

	Click this as to enter in to attributes page, users can modify program name or set timing playing. If you choose timing playing, you can set start date, end date, start time, end time, week, etc.
	Add area
	Edit attribute in selected area
	Zoom in/out in preview
	预览界面复位 Reset preview page
	预览界面锁定和解锁 Lock or unlock preview page
	所选区域最大化 Maximization of selected area
	删除节目 Delete program
	所选区域上移/下移一层 Move up/Shift down for selected area
	保存节目 Save program
	返回上一级 Return to last step
	发送节目 Send program

	文字颜色 Text color
	文字背景色 Text background color
	区域背景色 Area background color
	文字全选 Select all text


## 2. Add video area

Click “video area” icon, select AddScreen, enter into your video list, choose the video you need to add in.

- In preview, click  button to enter into video attributes page, select one video, to modify resolution, play time, frame, etc. After finish editing, click any other area as to exit.
- Adjust video area size or move video position.



## 3. Add picture area



Click “Picture” icon, select “AddPicture” , enter into your picture list, choose the picture you need to add.

- In preview, click  button to enter into picture attributes page, to modify display stunt, running speed, staying time, frame, etc. After finish editing, click any other area as to exit.
- Adjust picture area size or move picture position.

## 4. Add text area


Click “text area” icon, click preview area of screen, input words directly.

- In preview area, click  button to enter into text attributes page, single line display or not, users can modify display stunt, running speed, staying time, frame, etc.
- Text attribute page, click  to edit font size, bold, italic, underline, text color, text background color, alignment, etc.
- Adjust text area size or move text position.




## 5. Add time area

Click “time area” icon, add one time area

- In preview area, click  button to enter into time attributes page, single line display or not, users can modify font type, font size, font color, frame, etc. After finish editing, click any other area as to exit.
- Click “type” , set time display format, display date, week parameters or not.
- Adjust text area size or move text position.


## 6. Add timer area

Click “timer” icon, add a timer area.

- In preview area, click  button to enter into time attributes page, single line display or not, users can modify date, time, font type, font size, frame, etc. After finish editing, click any other area as to exit.
- Click “type” , set unit, display day, hour, minute, seconds or not.
- Adjust text area size or move text position.


## 7. Add dial area

Click “dial area” icon, add one dial area.

- In preview area, click  button to enter into dial attributes page, users can modify font type, font size, add fixed text, text color, frame or not. After finish editing, click any other area as to exit.
- Click “type” , users can set dial type, color, colors of hands/minute hands/second hands.
- Adjust text area size or move text position.


## 8. Add colorful words area

Click “colorful words” icon, add one colorful area.

- In preview area, click  button to enter into colorful words attributes page, users can modify dial type, dial color, colors of hands/minute hands/second hands, etc. After finish editing, click any other area as to exit.
- Adjust text area size or move text position.

## 9. Add colorful background area


Click “colorful background area” icon, add one colorful background area.

- In preview area, click  button to enter into colorful background area attributes page, users can modify texture type, texture size, texture density, stunt, running speed and moving direction, etc. After finish editing, click any other area as to exit.

- Adjust text area size or move text position.


## 10. Add weather area

Click “weather area” icon, add one weather area.

- In preview area, click  button to enter into weather area attributes page, users can modify city, font type, font size, font color, alignment, stunt, running speed, staying time, frame, etc. After finish editing, click any other area as to exit.
- Click “type” , set weather type, display in single line, city name or not.
- Adjust text area size or move text position.


## 11. Add temperature area

Click “temperature” icon, add one temperature area.

- In preview area, click  button to enter into temperature area attributes page, users can modify temperature type, access point, unit, precision, modification value, display fixed text or not, font type, font size, normal colors, alarm condition, alarm color, frame, etc. After finish editing, click any other area as to exit.
- Adjust text area size or move text position.


## 12. Add humidity area

Add “humidity area” icon, add one humidity sensor.



- In preview area, click  button to enter into humidity area attributes page, users can modify sensor type, access point, unit, precision, modification value, display fixed text or not, font type, font size, normal colors, alarm condition, alarm color, frame, etc. After finish editing, click any other area as to exit.
- Adjust text area size or move text position.

## Send program

After edit program, click send button  , enter into send list, and choose correct controller, then send. As below:




## **Manage program**


In APP, users can see all screen list you added, you can add many programs in one screen, and add many areas in one program (like video, picture, text, etc.), click   as to adjust position.

## **Function setting**


### **Set ON/OFF**

In APP, click  ON/OFF button, as to turn on/off screen. Turn off is only disconnect signal, screen will be black, but not turn off the power supply.


### **Timing on/off**

In APP, click  button, as to turn on/off screen in times.


### **Correction time**

Click  as to correct time.


### **Brightness**

Click  to set brightness, right/left slide mobile screen to adjust brightness value, 1 is black, 16 is maximum bright.


### **Volume**

Click  to set volume, right/left slide mobile screen to adjust volume value, 1 is the lowest, 100 is the highest.


### **Set screen parameters**

Click  to set screen width, height, and rotation.


### **Switch storage**

Click  to switch storage, users can choose storage, SD card or U disk storage method.

## **WIFI configuration**

Click  WIFI configuration button, enter in to WIFI configuration page, users can modify WIFI name and passwords of controller.

## **Firmware update**

Click  firmware updating button, when it detects that this controller is not the latest version firmware, will update into the latest one automatically.

## **Other settings**

### **Language**

Click "language" , users can choose "follow system language" , "Simplified Chinese" , "Traditional Chinese" , "English" and "Russian" or "Vietnamese" .

### **Clean cache**

In "setup" of APP, click "clean cache" , as to clean software cache.

### **App Share APP**

In "setup" of APP, click "share APP" , it will show QR code of software, users can copy QR code to customers.

### **Version**

In "setup" of APP, click "version" , users can check present version.

## Contact Us

### Shanghai ONBON Technology Co.,ltd (Headquarters)

Address: 7 Floor, Tower 88, 1199#, North Qinzhou Road, Xuhui District, Shanghai City, China

Tel Phone: 086-21-64955136

Fax: 086-21-64955136

Website: [www.onbonbx.com](http://www.onbonbx.com)

### ONBON (Jiangsu) Optoelectronic Industrial Co.,LTD

Address: 1299#, Fuchun Jiang Road, Kunshan City, Jiangsu Province, China

### Sales Contacts

Tel: 0086-15921814956 0086-15800379719

Email: [onbon@onbonbx.com](mailto:onbon@onbonbx.com)

### Second Development

Tel: 0512-66589212

Email: [dev@onbonbx.com](mailto:dev@onbonbx.com)

### iLEDCloud

Website: <http://www.iledcloud.com/>

