



IR controller User Manuel

Version : V1.0 Date : 2016.10.8


Statement

Any companies or privates cannot copy, transcribe or translate part or whole content of this file without our written permission. And cannot use it on any business or benefit filed with any forms. The specifications and information which are mentioned on the file is for reference only, if there's update, we will not inform you. This file is only for guidance, and all information will not be for any promises.

Product photos

The maximum remote control distance of the infrared remote controller for BX controller is 12M, and the remote control angle is 45 degree.





Notice : There will be 2 seconds delay after select the programs.

Attention :

- 1) Users should use this IR controller specially for BX controller.
- 2) The infrared receiving head is recommended to be installed at the button or the button part of the side of the LED screen to avoid signal weaken. And ensure that the angle when operating the remote control should be ± 45 degrees.
- 3) When the IR controller is not sensitive, check the battery of it. If the battery is insufficient, please replace it in time.



Simple operation instruction

Key function instruction

Power Power On/Off controller

MENU Unlock program

TEST Enter into test mode

+ Add brightness

- Lower brightness

↶ Quit test mode

⏪ Last program

⏩ Display /Stop

⏮ Next program

0-9 Key Select program

Note: There might be 2 seconds delay once select the program.